



since 1894 by

STOOPEN & meeûs

Technical Datasheet CrustalFix

DESCRIPTION

CrustalFix is used to fix pigments used with CrustalAccent.

CrustalAccent is an additional adaptation with pigments on Crustal, to apply more or less subtle tints. When Crustal has dried, the surface must be moistened with water in which 0.5% CrustalDispers has been added to reduce the extraction. Then add to water with 0.5% CrustalDispers, 1 to 5% pigment and apply with roll, brush or sponge until reaching the desired tints. After drying, CrustalFix is applied with a roll in a thin, equal layer, which will not change the aspect anymore. Do not apply plentiful CrustalFix to avoid possible drying rests in deeper parts.

CrustalFix will fix the pigments but does not offer protection against stains or moisture.

TECHNICAL FEATURES

Type of delivery	Acrylate dispersion
Number of layers	Mostly 1 thin, equal layer is sufficient
Consumption	15 to 20 m ² /L, depending on the technique
Drying time	Until 1 hour

Temperature	Environmental and surface temperature between 8 and 25°C
Shelf-life	Closed packing, stir before use
Tools	Roll
Cleaning	Water

PRECAUTIONS

Use CrustalFix in a well aerated room. IN CASE OF CONTACT WITH THE EYES: Rinse carefully with water for a couple of minutes. Take off contact lenses, if possible. Continue rinsing. Keep out of reach of children.

NOTICE

Stoopen & Meeûs accepts the responsibility for the quality of its products, however does not accept any liability for the application of these products. Always consult the technical sheet of the product on the website.

E: info@stoopen-meeus.com
T: +32 (0)3 825 00 55

Stoopen & Meeûs nv
Van Praetstraat 22 B-2660 Hoboken, Belgium
VAT: BE 0450 824 623

Rev. : 28/08/2018

www.stoopen-meeus.com